

ShenZhen Chainway Information Technology Co., Ltd

Mobile Data Terminal

MC50 User Manual



Content

Content.....	1
Statement	3
Chapter 1 Product intro	5
1.1 Intro	5
1.2 Precaution before using battery	6
1.3 Notes	7
Chapter 2 Installation instructions	8
2.1 Appearance	8
2.2 Install Micro SD and SIM cards	8
2.3 Battery charge	10
2.4 Buttons and function area display	11
Chapter 3 Call function	12
3.1 Calling numbers	12
3.2 Contacts	12
3.3 5G Function	12
3.4 SMS and MMS	12
Chapter 4 Barcode reader-writer	13
Chapter 5 RFID reader	15
5.1 NFC	15
Chapter 6 Other functions	16
6.1 PING tool	16
6.2 Bluetooth	17
6.3 GPS	18
6.4 Volume setup	19
6.5 Sensor	20
6.6 Keyboard	21

6.8 Network	22
6.8 Keyboard emulator.....	23
Chapter 7 Device characteristic	25

Statement

©2013 by ShenZhen Chainway Information Technology Co., Ltd. All rights reserved.

No part of this publication may be reproduced or used in any form, or by any electrical or mechanical means, without permission written from Chainway. This includes electronic or mechanical means, such as photocopying, recording, or information storage and retrieval systems. The material in this manual is subject to change without notice.

The software is provided strictly on an “as is” basis. All software, including firmware, furnished to the user is on a licensed basis. Chainway grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Chainway. No right to copy a licensed program in whole or in part is granted, except as permitted under copyright law. The user shall not modify, merge, or incorporate any form or portion of a licensed program with other program material, create a derivative work from a licensed program, or use a licensed program in a network without written permission from Chainway.

Chainway reserves the right to make changes to any software or product to improve reliability, function, or design.

Chainway does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or by implication, estoppel, or otherwise under any Chainway intellectual property rights. An implied

license only exists for equipment, circuits, and subsystems contained in Chainway products.]

Chapter 1 Product intro

1.1 Intro

Our new 5G large-screen smart handheld terminal uses Android 12 operating system, high-performance eight-core processor, optional large-capacity memory, 6-inch high-definition large screen, and 5000mA removable battery, which is excellent in configuration and efficient in operation. It can integrate data acquisition functions such as barcode, NFC, front and rear cameras, and has excellent performance such as IP68 high protection level, 1.5m drop resistance, etc. It is rich in functions and durable, and perfectly adapts to the applications of retail, logistics, warehousing, power, finance, transportation, manufacturing, etc., helping users significantly improve their work efficiency and obtain greater benefits with less investment.

1.2 Precaution before using battery

- Do not leave battery unused for long time, no matter it is in device or inventory. If battery has been used for 6 months already, it should be checked for charging function or it should be disposed correctly.
- The lifespan of Li-ion battery is around 2 to 3 years, it can be circularly charged for 300 to 500 times. (One full battery charge period means completely charged and completely discharged.)
- When Li-ion battery is not in use, it will continue to discharge slowly. Therefore, battery charging status should be checked frequently and take reference of the related battery charging information on the manuals.
- Observe and record the information of a new unused and non-fully charged battery. On the basis of operating time of new battery and compare with a battery that has been used for long time. According to product configuration and application program, the operating time of battery would be different.
- Check battery charging status at regular intervals.
- When battery operating time drops below about 80%, charging time will be increased remarkably.
- If a battery is stored or otherwise unused for an extended period, be sure to follow the storage instructions in this document. If you do not follow the instructions, and the battery has no charge remaining when you check it, consider it to be damaged. Do not attempt to recharge it or to use it. Replace it with a new battery.
- Store the battery at temperatures between 5 °C and 20 °C (41 °F and 68 °F).

1.3 Notes

Note:

Using the incorrect type battery has danger of explosion.
Please dispose the used battery according to instructions.

Note:

Due to the used enclosure material, the product shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

Note:

The adapter shall be installed near the equipment and shall be easily accessible.

Note:

The suitable temperature for the product and accessories is -20°C to 50°C.

Note:

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Chapter 2 Installation instructions

2.1 Appearance



2.2 Install Micro SD and SIM cards

The cards sockets are showing as follows:



2.3 Battery charge

By using USB Type-C contact, the original adaptor should be used for charging the device. Make sure not to use other adaptors to charge the device.

2.4 Buttons and function area display

The device is divided into five side buttons on the button. There is a two-dimensional scanning head on the top of the body, a high-definition camera and a flash light on the rear of the body, and an NFC recognition area is below the camera.

Button		Details
Side-buttons	1. Power	Right-side of device,power ON/OFF.
	2.SCAN	Both sides of device,scan function.
	3.VOLUME	Volume +/-
	4.Multi-function	Self-define

Chapter 3 Call function

3.1 Calling numbers

1. Click icon .
2. Click number key to input phone numbers.
3. Click icon  to call.
4. Click icon  to end call.

3.2 Contacts

1. Click contacts to open contacts list.
2. Click icon  to add new contacts.

3.3 5G Function


1. Open Settings
2. Select Network and Internet
3. Select SIM card
4. Enable 5G

3.4 SMS and MMS

1. Click  to open message window.
2. Click  to input message receiver and contents.
3. Click  to send out messages.

Chapter 4 Barcode reader-writer

1. In App Center, to open 2D barcode scan test.
2. Press “SCAN” button or click scan key to start scanning, the parameter “Auto interval” can be adjusted.



 Caution: Please scan codes in correct way otherwise the scanning will be failed.

2D code:



Correct



Incorrect



Max. radiant power: 0.6mW

Wave length: 655nm


IEC 60825-1 (Ed.2.0).

21CFR 1040.10 and 1040.11 standard.

Chapter 5 RFID reader

5.1 NFC


Click App Center, open “NFC” to read and write tag information.



Chapter 6 Other functions


6.1 PING tool

1. Open “PING” in App Center.
2. Setup PING parameter and select external/internal address.




6.2 Bluetooth

1. Open “BT Printer” in App Center.
2. In the list of detected devices, click the device that you want to pair.
3. Select printer and click “Print” to start printing contents.




6.3 GPS

1. Click “GPS” in App Center to open GPS test.
2. Setup GPS parameters to access GPS information.




6.4 Volume setup

1. Click “Volume” in App Center.
2. Setup volume by requirements.



6.5 Sensor

1. Click “Sensor” in App Center.
2. Setup the sensor by requirements.




The screenshot shows the 'Sensor' app interface. At the top is a blue header with a back arrow, a sensor icon, the text 'Sensor', and the word 'KEYBOARD' on the right. Below the header is a section titled 'Light' in a light gray bar. Under 'Light', there are three radio buttons labeled 'R' (red), 'G' (green), and 'B' (blue). The 'R' radio button is selected. To the right of these are two gray buttons labeled 'Open' and 'Auto'. Below the 'Light' section is another section titled 'Sensor' in a light gray bar. Under 'Sensor', the text 'P-Sensor value: 1.0' and 'Light Sensor value: 5.0' is displayed.




6.6 Keyboard

1. Click “Keyboard” in App Center.
2. Setup and test the main value of the device.



6.8 Network

1. Click “Network” in App Center.
2. Test WIFI/Mobile signal by requirements.



6.8 Keyboard emulator

The keyboard emulator can be used in multiple operating background and output formats directly. And it includes Prefix/Suffix/Enter/TAB.

Please check Keyboard emulator manual for more details.

Note:

For each model, keycode of side button would be different, user needs to use keyboard in appcenter to check keycode and bind in Barcode2D.

19:52

100%

keyboardemulator v7.4.0.6

Function

AppSettings

2DSettings

Test

Enable Scanner

ON

Barcode	KeyCode	
☒ Barcode2D	291	293
	294	296

UHF	KeyCode	
☐ UHF	291	294

Chapter 7 Device characteristic

Physical characteristics

Size	161.0 x 77.8 x 15.5mm / 6.34 x 3.06 x 0.61in.
Weight	269g / 9.49oz. (device with battery)
Keypad	Power key, 2 scan keys, volume (+/-) keys
Display	6-inch high definition display (18:9), 1440 x 720
Touch panel	Corning Gorilla Glass, multi-touch panel, gloves and wet hands supported
Sensor	G_sensor, proximity sensor, light sensor, geomagnetic sensor, gyroscope
Battery	5000mAh removable main battery, support QC3.0 and RTC
Notification	Sound, LED indicator, vibrator
Expansion Slot	1 for SIM card, 1 for SIM or TF card
Interfaces	USB Type-C, USB 3.1, OTG

Performance

CPU	Qualcomm Snapdragon™ 480 Octa-core, 2.0GHz
OS	Android 12
RAM	4GB
Communication Interface	USB3.1, Type-C, OTG
ROM	64GB
Max. expansion	Supports up to 256 GB Micro SD card

User environment

Operating temp.	-20°C to 50°C
Storage Temp.	-40°C to 70°C
Humidity	5%RH - 95%RH non condensing
Sealing	IP65, IEC sealing standard
Drop specification	Multiple 1.5m / 4.92ft. drops (at least 28 times) to the concrete across the operating temperature range
Tumble Specification	1000 x 0.5m / 1.64ft. falls at room temperature
Sealing	IP67 per IEC sealing specifications
ESD	±15 KV air discharge, ±8 KV conductive discharge

Communication

WAN	2G: 850/900/1800/1900 MHz 3G: 850/900/1900/2100MHz 4G:B1/B2/B3/B5/B7/B8/B20/B28A/B28B/B34/B38/B39 /B40/ B41 5G: N1/N3/N8/N28/N41/N78/N79
Vo-LTE	Support Vo-LTE HD video voice call
WLAN	Support 802.11 a/b/g/n/ac/ax-ready, 2.4G/5G dual-band, IPV4, IPV6, 5G PA; Fast roaming: PMKID caching, 802.11r, OKC Operating Channels: 2.4G (channel 1~13), 5G (channel 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 144, 149, 153, 157, 161, 165), Depends on local regulations. Security and Encryption: WEP, WPA/WPA2-PSK(TKIP and AES), WAPI-PSK—EAP-TTLS, EAP-TLS, PEAP-MSCHAPv2, PEAP-LTS,PEAP-GTC, WPA3-Enterprise, WPA3-Enhanced Open, WPA3 Easy Connect, WPA3-Personal, etc.

Bluetooth	Bluetooth 5.1
------------------	---------------

Data collection

Barcode scanning	Zebra: SE4710; Honeywell: N6603
Camera	Rear: 16MP Autofocus with flash Front: 5MP
RFID	NFC 13.56Mhz

Developing Environment

SDK	Chainway software develop kit
Language	Java
Develop	Eclipse/Android Studio